


Art. 160.2000



Art. 160.2000

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
1	160.2000-R001P	Gummiteller	Rubber Pad	1
2	160.2000-R002P	Schraube	Screw	1
3	160.2000-R003P	Aufnahmeteller	Saddle	1
4	160.2000-R004P	Schraube	Screw	4
5	160.2000-R005P	Vordere Rolle	Front Wheel	2
6	160.2000-R006P	Vordere Abdeckung	Front cover	1
7	160.2000-R007P	Schraube	Screw	4
8	160.2000-R008P	Hintere Rolle	Rear Wheel	2
9A	160.2000-R009P	Schraube	Screw	1
9B	160.2000-R010P	Schraube	Screw	1
10	160.2000-R011P	Unterlegscheibe	Washer	2
11	160.2000-R012P	Unterlegscheibe	Washer	2
12	160.2000-R013P	Lenkstangenaufnahme	Handle Yoke	1

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
13	160.2000-R014P	Bedienelement	Handle Assembly	1
14	515.6004	Akku	Battery	1
15	160.2000-R020P	Abdeckung Hydraulikeinheit	Pump Unit cover	1
16	160.2000-R021P	Schraube	Screw	4
17	160.2000-R022P	Arretierung Lenkstange	Handle Position Lever	1
18	160.2000-R023P	Tragegriff	Carrying Handle	1
19	160.2000-R024P	Hydraulikeinheit	Pump Unit	1
20	160.2000-R025P	Schraube	Screw	4
21	160.2000-R026P	Seitlicher Tragegriff	Side Handle	2